


INOUT08 - POSITION TRANSMITTER, POTENTIOMETERS
INOUT08 - VYSILAC POLOHY, POTENCIOMETRY



POSITION TRANSMITTER
FESTO SMAT-8E

POTENTIOMETERS AND ANALOG INPUTS CAN BE MIXED.
IF POTENTIOMETERS ARE USED, 1. ANALOG INPUT MUST BE OMITTED.
ANALOG INPUTS FOR NON PRECISE MEASUREMENTS ONLY.

POTENCIOMETRY A ANALOGOVE VSTUPY SE MOHOU KOMBINOVAT.
POKUD JSOU POUZITY POTENCIOMETRY, NEMUZE SE POUZIT 1. ANAL. VSTUP
ANALOGOVE VSTUPY POUZE PRO ORIENTACNI MERENI - NEPRESNE.

MEFI s.r.o		
Size A	Document Number INOU8AP2	REV
Date: March 30, 2007	Sheet 1	of 1