

PRIPOJENI TOCITKA K BEZP. MODULU BECKHOFF
MANUAL WHEEL CONNECTION TO BECKHOFF MODULE

